

Litemate® Connectors

Complete System Vehicle-to-Trailer Wiring Assembly Vehicles with Rear Factory Electrical Connectors

EASY INSTALLATION USING

- > Factory Connector
- > Litemate Vehicle Connector
- > Litemate Trailer Connector

Connectors based on vehicle make, model & year. See current Selection Guide for update information.



UNIVERSALS

#6588P (#6588PT)
All Years & Models Extends to 11'
Vehicles With Rear Red Turn Signals Or
Common Bulb For Turn Signals & Brake Lights



#6589P (#6589PT)
All Years & Models Extends to 11'
Vehicles With Rear Amber Turn Signals
Or Separate Bulbs For Turn Signals & Brake Lights



TOYOTA/HONDA/ISUZU/NISSAN

#6742P (#6742PT) 2001-02 Toyota Tundra	#6753P (#6753PT) 1996-04 Nissan Pathfinder & Infiniti QX4
#6743P (#6743PT) 1998-04 Honda Passport & Isuzu Rodeo	#6754P (#6754PT) 1997-01 Nissan Altima
#6744P (#6744PT) 1998-03 Isuzu Rodeo Sport, Amigo	#6755P (#6755PT) 1996-00 Honda Acura SLX
#6745P (#6745PT) 1999-00 Toyota Tundra	#6756P (#6756PT) 1992-02 Isuzu Trooper
#6746P (#6746PT) 1998-04 Nissan Frontier Pickup	#6757P (#6757PT) 1991-97 Nissan Pickup
#6747P (#6747PT) 1996-00 Toyota RAV4	#6758P (#6758PT) 1994-01 Acura Integra
#6748P (#6748PT) 1996-02 Toyota 4-Runner	#6759P (#6759PT) 1995+ Honda Odyssey, CRV, Pilot
#6749P (#6749PT) 1991-98 Toyota Land Cruiser	#6760P (#6760PT) 1996-98 Isuzu Oasis
#6750P (#6750PT) 1996+ Subaru Outback & Forester	#6761P (#6761PT) 1996-03 Honda Acura CL/RL/TL
#6752P (#6752PT) 2005-07 Nissan Pathfinder w/Tow	#6762P (#6762PT) 2001-06 MDX
#6753P (#6753PT) 2005-06 Nissan Frontier, Xterra w/Tow	#6763P (#6763PT) 1994-02 Honda Accord & Wagon



FORD

#6862P (#6862PT) 2002-04 F-250 Heavy Duty & F-350	#6874P (#6874PT) 1987-88 Bronco Full Size
#6863P (#6863PT) 2002-04 Explorer / Mercury Mountaineer	#6875P (#6875PT) 1989-91 Bronco Full Size (Except Bronco II)
#6864P (#6864PT) 1996-99 Taurus & Mercury Sable	#6876P (#6876PT) 1987-91 Bronco II
#6865P (#6865PT) 1992-96 Full Size Bronco	#6878P (#6878PT) 1991-94 Explorer & Mazda Navajo
#6866P (#6866PT) 1992-97 Crown Victoria & Mercury Grand Marquis	#6879P (#6879PT) 1994-99 Ranger & Mazda B Series Pickup
#6867P (#6867PT) 1992-95 Taurus (Sedan Only)	#6880P (#6880PT) 1996-97 Explorer & Mercury Mountaineer
#6868P (#6868PT) 1995-00 Explorer & Mercury Mountaineer w/out Tow	#6881P (#6881PT) 1995-00 Explorer w/Tow Package
#6869P (#6869PT) 1992-97 Windstar	#6882P (#6882PT) 1996-01 Mercury Mountaineer w/Tow Pkg
#6870P (#6870PT) 1987-96 F-150, F-250 LD, F-350	#6883P (#6883PT) 1998-99 Ranger & Mazda w/Tow Package
#6871P (#6871PT) 1996-97 F-250 HD & F-350	#6884P (#6884PT) 1997 Pickups F-150, F-250 Light Duty
#6872P (#6872PT) 1986-92 Ranger Pickup	#6885P (#6885PT) 1997-99 Expedition/Lincoln Navigator
#6873P (#6873PT) 1979 & Earlier Pickup All Sizes	#6886P (#6886PT) 1995-98 Aerostar
#6874P (#6874PT) 1980-86 Pickup & Bronco Full Size	#6887P (#6887PT) 1995-03 Full Size Vans & ZX2

DODGE/CHRYSLER/PLYMOUTH

#6981P (#6981PT) 1993-98 Full Size Van	#6986P (#6986PT) 1987 Full Size Pickup
#6982P (#6982PT) 1995-02 Full Size Pickup/Dakota Pickup	#6987P (#6987PT) 1988-94 Dakota
#6983P (#6983PT) 1996-00 Dodge Caravan, Plymouth Voyager & Chrysler Town & Country	#6988P (#6988PT) 1988-93 Ram Charger / Trailduster
#6984P (#6984PT) 1998-03 Durango	#6989P (#6989PT) 1991-95 Dodge Caravan, Plymouth Voyager & Chrysler Town & Country
#6985P (#6985PT) 2001-03 Dodge Caravan	#6990P (#6990PT) 2004-07 Dakota Pickup
#6986P (#6986PT) 2002-06 1500 Ram Pickup	#6991P (#6991PT) 2007+ Dodge 1500/2500/3500 Pickup
#6987P (#6987PT) 2003-06 2500/3500 Ram Pickup	#6992P (#6992PT) 2004-07 Dodge Caravan, Plymouth Voyager & Chrysler Town & Country

JEEP

#6945P (#6945PT) 1993 Grand Cherokee	#6949P (#6949PT) 1982 & Earlier Cherokee Wagon
#6946P (#6946PT) 1994 Grand Cherokee	#6950P (#6950PT) 1997-01 Cherokee Wagon
#6947P (#6947PT) 1994-98 Grand Cherokee without Tow Package	#6951P (#6951PT) 1991-97 Wrangler / Renegade / YJ
#6948P (#6948PT) 1991-96 Cherokee Wagon	#6952P (#6952PT) 1998-04 Wrangler / Renegade / YJ
	#6953P (#6953PT) 1999-04 Grand Cherokee
	#6954P (#6954PT) 2005-06 Wrangler

CHEVY & GMC

#6760P (#6760PT) 1984 & Earlier Full Size Pickup/Blazer/Jimmy/Suburban	#6764P (#6764PT) 1995-05 Blazer / Trail Blazer / Jimmy / Olds Bravada / Astro / Safari
#6761P (#6761PT) 1985-87 Full Size Pickup	#6765P (#6765PT) 1999-01 Envoy
#6762P (#6762PT) 1985-91 Full Size Blazer/Jimmy/Suburban	#6766P (#6766PT) 1992-94 S-10 Blazer/S-15 Jimmy (2 DR)
#6763P (#6763PT) 1985-97 S-10 & S-15 Pickup/Sonoma	#6767P (#6767PT) 1987-96 Full Size Vans / Vandura (Except Express & Savana)
#6764P (#6764PT) 1996-97 Isuzu Hombre	#6768P (#6768PT) 1998-04 S-10/ S-15/Sonoma Pickup
#6765P (#6765PT) 1991-92 Cyclone	#6769P (#6769PT) 1998-00 Isuzu Hombre
#6766P (#6766PT) 1988-00 Full Size Pickup (Old Body)	#6770P (#6770PT) 1996-99 Express & Savana Full Size
#6767P (#6767PT) 1992-99 Full Size Suburban	#6771P (#6771PT) 1999-02 Silverado & Sierra with Tow
#6768P (#6768PT) 1992-94 Full Size Blazer & Jimmy	#6772P (#6772PT) 2000-02 Express & Savana Van
#6769P (#6769PT) 1995-99 Full Size Tahoe & Yukon	#6773P (#6773PT) 2004+ Colorado & Canyon
#6770P (#6770PT) 1999-00 Denali	#6774P (#6774PT) 2003+ Express & Savana Van
#6771P (#6771PT) 1999 Cadillac Escalade	
#6772P (#6772PT) 1984-91 S-10 Blazer/S-15 Jimmy (2 DR)	

TRAILER PRO CONNECTORS #7865C through #7764C See Selection Guide or Consult Factory

MULTI-TOW CONNECTORS New or Retrofit Factory 7-Way on 1999-2008 Vehicles See Selection Guide For Current Vehicle Listings

Ford / Lincoln / Mercury / Chevy / GMC / Olds / Cadillac

Chrysler / Dodge / Jeep



#6780P (#6780PT)
7-Way RV Blade & 4-Way Flat



#6781P (#6781PT)
6-Way Round & 4-Way Flat



#6782P (#6782PT)
7-Way RV Blade & 4-Way Flat