

Fuse Holders

Nylon In-Line Fuse Holder With Fuse
#0900 - 14 GA 20 AMP #0901 - 14 GA 30 AMP

Part #	Qty	Part #	Qty	Part #	Qty	Part #	Qty
0900A	100	0900C	1	0900PT	1	0900L	Card of 9
0901A	100	0901C	1	0901PT	1	0901L	Card of 9

In-Line Fuse Holder With Universal Nylon Body
#0905 - 16 GA 15 AMP #0906 - 12 GA 30 AMP

Part #	Qty	Part #	Qty	Part #	Qty	Part #	Qty
0905A	100	0905C	1	0905PT	1	0905L	Card of 9
0906A	100	0906C	1	0906PT	1	0906L	Card of 9

ATC/ATO Type Fuse Holders
#0961 - 16 GA 10 AMP #0963 - 12 GA 20 AMP

Part #	Qty	Part #	Qty	Part #	Qty	Part #	Qty
0961A	100	0961C	1	0961PT	1	0961L	Card of 9
0963A	100	0963C	1	0963PT	1	0963L	Card of 9

Mini Fuse Holder With Dust Cap & 12" Wire
#0965 - 16 GA 10 AMP #0967 - 12 GA 30 AMP

Part #	Qty	Part #	Qty	Part #	Qty
0965A	100	0965C	1	0965PT	1
0967A	100	0967C	1	0967PT	1

PVC Maxi Fuse Holder With Dust Cap
12" Red 8 Gauge Wire
60 AMP (Does not include fuse)

Part #	Qty
0969A	25
0969C	1
0969PT	1

Self-Stripping Fuse Holder
Locate New Fuse Position
Insert Wire & Crimp
Mates With Blade Type Fuses
20 AMP Maximum (Blue)

Part #	Qty
0972A	100
0972C	2
0972PT	2
0972L	Card of 9

Weather Resistant Fuse Holder
Nylon Body With Latching Cap
Rubber Seal Protects Fuses
12 GA 3 to 30 AMP

Part #	Qty
0950A	25
0950C	1
0950PT	1

Add-A-Circuit

#0956 - Mini Fuses #0957 - ATO Fuses (Fuses Not Included)

Plug Into An Existing Fuse Holder
Protects Original Circuit & Provides
A Wire Lead For New Circuit
16 Gauge 10 AMP

Part #	Qty	Part #	Qty	Part #	Qty
0956A	25	0956C	1	0956PT	1
0957A	25	0957C	1	0957PT	1

Fusible

Fusible Links "Open" Circuit When Overload Occurs
Prevents Damage To Wire Harness
Fusible Links Are NOT Intended To Replace Fuse
Use In Conjunction With Fuse

Extreme Caution should be taken when replacing a Fusible Link making sure an exact replacement of gauge and length as installed by original manufacture is used.



Part #	Part #	AWG	Stud	Length	Color	Description
5550P	5550PT	16 Ga	1/4"	9 1/4"	Black	GM Starter Solenoid
5551P	5551PT	14 Ga	3/8"	9 1/2"	Black	GM Starter Solenoid

Part #	Part #	AWG	Stud	Length	Color	Description
5552P	5552PT	18 Ga	5/16"	10 1/2"	Red	Ford Starter Solenoid
5553P	5553PT	16 Ga	5/16"	10 1/2"	Orange	Ford Starter Solenoid
5554P	5554PT	14 Ga	5/16"	10 1/2"	Green	Ford Starter Solenoid

Part #	Part #	AWG	Length	Color	Description
5555P	5555PT	18 Ga	8"	Black	Chrysler & Universal Ignition Battery
5556P	5556PT	16 Ga	8"	Black	Chrysler Feed, W/W, R/Window Defogger
5557P	5557PT	20 Ga	8"	Black	Universal

All Items with QT, KT or PT Suffix are Clam Shell Program Items.

Fuse Adapters & Terminals

Brass .250 Male Tab
Taps Into Glass Type Fuse Blocks
(Fuse Not Included)

Part #	Qty
1590A	1000
1590C	50
1590D	9
1590M	3
1590PT	50
1590KT	9
1590QT	3

ATC Brass Fuse Tap For GM (.250 Tab)
Snaps Over Blade Fuses
(Fuse Not Included)

Part #	Qty
1592A	1000
1592C	50
1592D	4
1592PT	50
1592KT	4
1592QT	2

ATM Brass Mini Fuse Tap
Slips Over Mini Fuse Blade (.187 Tab)
(Fuse Not Included)

Part #	Qty
1593A	1000
1593C	50
1593D	4
1593PT	50
1593KT	4
1593QT	2

Brass Terminal For ATO Fuse Block
Use With #0910

Part #	Qty
1598A	1000
1598C	50
1598D	5
1598PT	50
1598KT	5

Panel Mount Fuse

Mounts In Dashboard
Unscrew End to Replace Fuse
Use With .187" or .205" Female
(Does Not Include Fuse)
10 AMP 250 Volt AC
15 AMP 125 Volt AC

Part #	Qty
0922A	25
0922C	1
0922PT	1

GM Fuse Block Taps

Taps Into GM Fuse Block
Splice Accessory Wire Onto 16 Ga Connector Wire
Plug Connector Into Cavity

Use In Battery Cavity
Power Always On
Clock, Alarm, Radio, Horn
Black Housing

Part #	Qty
0951A	25
0951C	1
0951PT	1

Use In Ignition Cavity
Power Supplied Once
Ignition Is On
Clear Housing

Part #	Qty
0952A	25
0952C	1
0952PT	1